

# HONDA MAINTENANCE SCHEDULE CALCULATOR

## 2006 Accord Coupe Canadian Maintenance Schedule

**The Honda Maintenance Minder System:** Helping Honda owners keep maintenance costs in check.

### What it does:

The Maintenance Minder™ found in Honda vehicles monitors a number of variables to determine when the time is right for you to bring your Honda in for a Genuine Honda Oil Change. When the remaining service life of your engine oil reaches 15%, you will be alerted on your dashboard by a "service due soon" message. Along with this message, a letter (A or B) indicating the required service type will appear. Depending on the mileage at the time of your required oil change, additional required maintenance items indicated by a numeric sub-symbol (1-6) will also appear. These sub symbols are accumulated between oil change intervals in order to make it convenient for you to properly maintain your Honda.

### What it doesn't do:

The Maintenance Minder™ does not monitor the engine oil level in your Honda. Maintaining proper engine oil level is critical to preserving engine life and trouble free operation, so ensuring your engine oil is at the right level by checking it regularly is a good habit to form – please see your owner's manual for details. If it has been more than 12 months since your last oil change, Honda requires the engine oil be changed regardless of the % service oil life displayed. Also, Maintenance Minder™ does not monitor brake pad thickness, brake fluid condition or tire tread depth. Ensuring that these critical items are within specification is important for your safety on the road. If your brake fluid is more than 3 years old, Honda requires you have it changed. Determining the condition of any of these items is something your Honda Dealer will be pleased to assist with.

Understanding Maintenance Minder™ and following the recommended Honda Maintenance Schedule is the best way to ensure a happy and lengthy Honda ownership experience. Every Honda owner has different driving characteristics, which means each has their own unique service requirements. To guarantee the job is done right to meet your specific needs, your Honda Dealer will use only Genuine Honda Parts installed by Honda Factory Trained Technicians who know your Honda better than anyone else. As the primary goal of Maintenance Minder™ is to ensure you're maintaining the car as needed, your Honda Technician will reset the Maintenance Minder™ according to the type of service you have completed on your Honda. Doing so allows the system to clearly determine the next maintenance items required at your next service visit.

For further details on your specific schedule, please speak to your Honda Dealer's Service Advisor.

### MAIN ITEM A

#### Factory Recommended Maintenance

- Replace engine oil.\*

### MAIN ITEM B/B1

#### Factory Recommended Maintenance

- Replace engine oil\* and filter.
- Rotate tires,\*\* inspect for wear and adjust pressure
- Service front and rear brakes.
- Inspect parking brake adjustments.
- Inspect tie rod ends, steering gear box and boots.
- Inspect suspension components.
- Inspect driveshaft boots.
- Inspect brake hoses and lines (including ABS)
- Check all fluid levels, condition of fluids and check for leaks.
- Inspect exhaust system.
- Inspect fuel lines and connections.

### SUB-ITEM 1

#### Factory Recommended Maintenance

- Rotate tires,\*\* inspect for wear and adjust pressure.

## SUB-ITEM 2

### Factory Recommended Maintenance

- Replace air cleaner element.
- Replace dust and pollen filter.
- Inspect and adjust drive belt.

## SUB-ITEM 3

### Factory Recommended Maintenance

- Replace transmission fluid.
- Replace transfer case fluid (4WD Trucks).

## SUB-ITEM 4

### Factory Recommended Maintenance

- Replace spark plugs.
- Replace timing belt and inspect water pump (V6 only).
- Inspect valve clearance.

## SUB-ITEM 5

### Factory Recommended Maintenance

- Replace engine coolant.

## SUB-ITEM 6

### Factory Recommended Maintenance

- Replace rear differential fluid (4WD Trucks, S2000).

Notes: \*Use only Genuine Honda motor oil with a viscosity specific to your vehicle.

\*\*Tires may require more frequent rotation depending on driving conditions, alignment and driving habits.

## SPECIFIC ADDITIONAL REQUIRED MAINTENANCE

Recommended services whichever comes first km/month	Specific Additional Required Maintenance
12,000 km	Replace rear differential fluid and every 24,000 km thereafter if vehicle is regularly driven in mountainous areas at very low speeds, or if vehicle is frequently used tow a trailer (4WD Trucks).
Every 24,000 km	Replace rear differential fluid if vehicle is regularly driven in mountainous areas at very low speeds (S2000).
Every 24,000 km	Replace air cleaner element if vehicle is regularly driven in dusty conditions.
Every 24,000 km	Replace dust and pollen filter if vehicle is regularly driven in urban areas with high concentrations of emissions from industry and diesel-powered vehicles.
48,000 km	Replace automatic transmission fluid (V6 Trucks) and transfer case fluid (4WD Trucks) and every 48,000 km thereafter if vehicle is regularly driven in mountainous areas at very low speeds, or if vehicle is frequently used tow a trailer.
100,000 km	Replace automatic transmission fluid and every 48,000 km thereafter if vehicle is regularly driven in mountainous areas at very low speeds, or if vehicle is frequently used tow a trailer (Accord)
100,000 km	Replace timing belt if vehicle is regularly driven in very low temperatures (under -29°C; -20°F, V6 only).
Every 256,000 km	Inspect idle speed.
Every 3 years	Replace brake fluid.

